



SPICA pipeline

Laurent DOMISSE


J.C. MALAPERT – E. BERTIN – F. MAGNARD

TERAPIX – IAP

Outline

- Terapix pipeline overview
- Architecture
- Installation
- Spica Automatic
- Web Interface
- Spica Database
- Spica Web
- Improvements
- Conclusion

Terapix pipeline overview



Snooppix overview



Utility for non-interactive download



Monitors the CADC-CFHTLS archive area



Selects of type of data to download



Checks for data with new Elixir history (new or reprocessed by CFHT)



Transfers these data to Terapix repository

Datatransfer

DataTransfer

node1 : 33.6 %

Virtual free disk : 433.107 GB
Total disk : 652.036 GB

node2 : 33.6 %

node3 : 33.6 %

node4 : 25.3 %

Virtual free disk : 487.207 GB
Total disk : 652.036 GB

node5 : 18.5 %

Virtual free disk : 1523.314 GB
Total disk : 1869.964 GB

node6 : 30.1 %

Virtual free disk : 1306.830 GB
Total disk : 1869.964 GB

node7 : 19.3 %

Virtual free disk : 1508.813 GB
Total disk : 1869.964 GB

node8 : 19.3 %

Files available in the directory
/data/clix/fc1/from_CADC/headervaild/ and
/data/clix/fc2/from_CADC/headervaild/

Get the header :

695665o.fits.gz
695666o.fits.gz
695667o.fits.gz
695668o.fits.gz
695722o.fits.gz

RUNIDs available in the directory
/data/clix/fc1/from_CADC/headervaild/ and
/data/clix/fc2/from_CADC/headervaild/

Runid	Number of images	Runid size	Disk space needed
03AF19	27	17.786 GB	71.145 GB
03AL01	284	187.079 GB	748.315 GB
03AL02	28	18.447 GB	73.788 GB
03AL03	288	189.720 GB	758.882 GB
03AQ97	80	52.691 GB	210.764 GB
03AQ98	9	5.929 GB	23.717 GB

[please click on the link](#)

Transfer mode selection :

☐ Automatic transfer of a RUNID
☒ Immediate transfer of a RUNID

[Change it](#)

RUNID immediate transfer

Move RUNID : [03AF19](#) into

FILTER : [All](#)

Transfer status : on going transfers or sleep
Automatic mode in 8 minutes and 55 seconds
Immediate mode in 0 minutes and 55 seconds

Configuration and help

[Editing configuration file](#)
[Color bar legend](#)
[How to configure DataTransfer](#)
[How to control free disk](#)
[How to transfer a file](#)
[How to know transfer history](#)
[How to force a file to be reloaded in the DB](#)

Data transfer analysis and control

[Runid distribution](#)
[Transfer history](#)
[Received data flow control](#)
[Runid status control](#)
[Filter usage control](#)
[View work in progress with immediate mode](#)
[View work in progress with automatic mode](#)

Copyright © 2003 Terapix - IAP - J.C. Malapert

Transfers the data monitored by SNOOPPIX from the data transfer repository disks to Terapix processing disks

Checks available disk space on each node and sends the data on disks with enough space to produce weight + flag map images


Makes statistics on images (period, RunID, filter, etc...) and stores meta-data on local DB

Can run automatically or manually

Runid distribution - Copyright © 2003 Terapix - Mozilla

File Edit View Go Bookmarks Tools Window Help

Back Forward Reload Stop <http://clix.iap.fr/admin/datatransfer/distribution.php> Search Print

 **TERAPIX** Welcome to Data Transfer

DataTransfer > Analysis and Control > Runid distribution


	node1	node2	node3	node4	node5	node6	node7	node8	node9	node10
03AL04	100.0% [2 files]	-	-	-	-	-	-	-	-	-
03AQ98	-	-	-	100.0% [10 files]	-	-	-	-	-	-
03AF19	-	-	-	-	100.0% [45 files]	-	-	-	-	-
03AL05	-	-	-	-	-	100.0% [49 files]	-	-	-	-
03AL01	16.1% [73 files]	-	-	-	-	50.7% [230 files]	24.7% [112 files]	-	6.6% [30 files]	17.0% [77 files]
03AL02	-	-	-	-	-	35.9% [28 files]	64.1% [50 files]	-	-	-
03AL03	-	20.8% [83 files]	-	-	-	-	-	31.8% [127 files]	47.4% [189 files]	-
03AQ97	19.9% [70 files]	16.2% [57 files]	13.6% [48 files]	-	-	-	-	65.6% [231 files]	-	20.5% [72 files]

Done



SPICA

Characteristics



- MegaCam data processing tool
- Data Flow control (based on runid/filter)
- Scamp, Swarp, Sextractor and QualityFITS tools
- Cluster/Standalone
- 5-level scripts
- Synchronous /asynchronous scripts
- Builds shell scripts to feed spica daemon
- Several Modes (survey/images/area...)
- Automatic (scripts) / Manual (Web) processing
- Handles MEF/CCD files
- Database storage (history / XML output)
- Web report


Architecture proposed at first

- Client/Server
 - Server prepares stacks
 - Server searches for available node
 - Server sends stack according to cpu, ram, disk node
- Redondant server
 - In case of hardware failure
- Database
 - Pipeline memory

Terapix constraints

- Nodes should be autonomous
 - No redundancy
 - No server
- I/O should be minimized
 - Data on the same node
 - Local output and remote output for CADC
- Release configuration « Frozen »
- Failure tolerances
 - Save pipeline status
- Can work with any image
 - Dynamic and flexible database (dbterapix)

Hardware configuration



History

- Pipeline CFH12k
 - No database, rsh
 - February 2002 – June 2002
- Spica Web
 - Elixir / Dbterapix / Astrometrix
 - June 2002 – June 2004
- Spica automatic
 - Spica / Dbspica / Scamp
 - June 2004 – March 2012


Installation

- Requirements :
 - Perl, PHP, MySQL, NFS (almost optional)
- Perl Modules:
 - DBI : database connector
 - Astro-WCS : compute WCS coordinates
 - XML-Simple : XML parsing
 - PDL : completeness graphs
- Spica : 3 packs + 1 db
 - Core : perl scripts (/usr/local/spica/)
 - Web interface : PHP scripts (/var/www/html/)
 - Configuration files (/usr/local/etc/spica/)
 - Database SQL table

QualityFITS in

- Synchronous Perl script (spica_ini.pl)
 - Runs on each node
 - One for each raid partition
 - 20 to 50 minutes per file
- Todo
 - Reprocessing
 - Using CFHT Metadata
 - Downloading masters from CFHT, from other nodes
 - Webservice ?
 - Faster but data is dispatched randomly => problems when crash occurs


QualityFITS in




Spica

- Perl script (spica_auto.pl)
 - Generates commands and launches scripts for each stack
 - Generates .head files (photometry)
 - Copies/Links weighted data from other nodes
 - Chooses files according to stacks rules
 - Filter, Exposure Time, Skyprobe, Seeing ...
- Daemon scripts
 - Chooses which stack to run (priority rules)
 - Restarts stopped stacks (software crash)

Spica running on nodes




Spica on each node



Spica

- Finds for each file located on the node
 - To which stack the file belongs
 - Lists files to be used by swarp
 - Makes symbolic links to other nodes (or copies the files)
 - Lists files to be used by scamp
 - Number of sources must be uniform across the field of view
 - Create .ahead for missing Phot_C, Scampcol, PhotFlag
 - Creates tree structure (temporary working directory)
- Finds Photometric files
 - Uses CFHT Meta-data (skyprobe, ranking)
- Generates one shell command file and one starting file per stack

Shell commands



Spica_auto

- Computing modes
 - Image by image (VW)
 - Stack (Wide, Pre-Wide, Deep)
 - PI ...
- Finds sky areas to stack
 - Automatic group selection
 - Sky grid
 - Loads location sky fields coord.
- Filtering rules
 - Filter, Exposure Time, Skyprobe, Seeing ...

Spica scripts (1)

- Spica_auto.pl
 - Generates shell command scripts for each stack
 - Prepares stack files according to filtering rules
 - Generates XML history
 - Fills dbspica
- Spica_daemon.pl
 - Executes the .spica file
 - .error, .processed, .processing status
- Spica_run.pl
 - Runs each shell command lines
 - Checks status control
 - Aborts and saves if problems

Spica scripts (2)

- Shell command files
 - Copies/Updates files
 - Executes applications and spica scripts
- Spica scripts
 - Database queries / loading XML
 - Input/Output management
 - Extracts sub-image/Comptness/thumbnails/ Update QF...

Stacks list

Terapix - Spica - Mozilla Firefox

http://clix.iap.fr/spica/admin/admin-spica/survey/list_app_files.php?filename=CFHTLS_Pre-W_r_021800-085200&imgid=171

Seti Spica Clubic Tootella HardWare PCNPact MonsieurPrix Prix Gravure Blue RER T  l  rama Google BLUEMARS - Music...

Terapix - Spica

TERAPIX

Home > Tools > Data reduction > Spica

[Export the whole result in CSV (ASCII file in Comma Separated Values)]

CFHTLS_Pre-W_r_021800-085200 - 146 files

Thumbnail	File	Header	Object	Runid	Filter	Ra	Dec	Exptime	DateObs	Seeing	Airmass	Skyprobe	Node
	811001p	811001p.head	Pre-W1_159	05BL02	r	02:17:59	-08:51:48	180.06	2005-09-09	0.91	1.165	10	mix4
	810998p	810998p.head	Pre-W1_159	05BL02	r	02:17:59	-08:51:46	180.098	2005-09-09	0.88	1.153	10	mix4
	810150p	810150p.head 810150p.ahed	Pre-W1_159	05BL02	r	02:17:59	-08:51:53	180.069	2005-09-03	0.94	1.185	10	mix4
	807009p		Pre-W1_129	05BL02	r	02:14:10	-06:59:44	180.059	2005-08-10	0.83	1.392	0.096	mix4
	807004p		Pre-W1_131	05BL02	r	02:14:10	-06:03:44	180.091	2005-08-10	1.06	1.491	0.076	mix4
	807003p		Pre-W1_130	05BL02	r	02:14:09	-06:31:43	180.088	2005-08-10	1.17	1.524	0.072	mix4
	807001p		Pre-W1_113	05BL02	r	02:12:15	-06:31:44	180.11	2005-08-10	0.95	1.565	0.078	mix4
	806999p		Pre-W1_145	05BL02	r	02:16:04	-07:27:44	180.115	2005-08-10	0.9	1.672	0.079	mix4
	806860p		w1.-1-0	05BL02	r	02:14:12	-07:02:00	500.083	2005-08-06	0.68	1.205	0.057	mix4

http://clix.iap.fr/spica/admin/admin-spica/survey/CFHTLS_Pre-W_r_021800-085200_T0003/scamp/810150p.head

Adblock

- Stacks list :
 - Pending
 - Running
 - Completed
- Files list :
 - Scamp
 - Swarp
- Priority
- Ranking
- Processing time

Spica scripts

- Spica_ini : QF
- Spica_auto : Prepares and generates stacks
- QF_xml : Loads XML QF into dbspica
- Spica_check : Checks before launch
- Spica_run : Runs each shell command
- Spica_daemon : Launches stacks
- Comptness : Computes comptness
- Stifbin : Thumbnails
- Spica_copy : Copies ldac node to node
- End_runid : Email, Symlink, Closes stacks
- Scamp_xml : Loads Scamp XML into dbspica
- Extract_subimage : Extracts stack subimage
- Ranking_auto : Stack notation
- Update_seeing : Updates FITS keyword
- Update_swarp_header : Updates external header
- Update_db_spica : SQL update
- Update_release_date : Updates FITS keywords
- Qf_db_spica : Updates QF output in dbspica
- Update_qf2 : Updates QF HTML page

PHP Scripts

- Display :
 - QF, Stacks report
 - Data management
 - Data-mining
- Dbspica management
- Spica Web
 - Data selection
 - User account
 - ...

Spica database (1)

- 29 tables
 - Application configurations (Spica Web)
 - Cluster configurations (node, user, path, problem)
 - QF XML output, Scamp XML, Comptness, WCS
 - Metadata (skyprobe)
 - Spica auto
 - Auto_status (stack list)
 - Auto_run (status list)
 - Auto_job (application list)
 - Auto_file (file list)
- Processing history
- Data-mining tool

Spica database (2)

- ClusterNode
 - cluster configuration (Ram,Cpu,Disk,Status)
 - Checks available node (via crontab script)
- Application
 - Name, Binary, Version, Date, Config files
 - Checks all nodes have the same binary
 - Updated when a new binary is installed
- Auto_view
 - Login, passwd, runid, email
 - Restricts access for Web interface
 - Updated with PI Data

Spica testing

- Pix3/Pix4 testing nodes
- How to use it :
 - Install images on pix3/pix4 node
 - Install/Update
 - Spica scripts
 - Applications
 - Configuration files (Release number + options)
 - Dbspica (version number)
 - Run QFin with spica_ini.pl
 - Run stacking with spica_auto.pl
 - If necessary to remove QFin/Stack, use Web interface

Software failure (1)

- Failure detection :
 - Spica_check before running each stack
 - Node status
 - Disks space
 - Stack status
 - Application version number
 - Idac repository used in case of node crash
- If a failure happens :
 - Spica processes the next stack
 - Spica sends Teraop Email
 - Spica changes Status in dbspica
 - Spica moves .processing to .error


Software failure (2)

- Standard procedure to recover from the failure :
 - Check files, solve the problems and restart
 - Rename launch script from .error to .spica (stack)
 - Remove lock file (QFin)
 - Change Status_spica flag in dbspica.auto_status
- Restart from the failed command (memorized by Spica when failure happened)
- Note : NFS dependence
 - Web interface
 - Swarp symbolic links (to avoid data transfer between nodes)

Hardware failure

- Sensitive hosts (not allowed to crash)
 - Dbterapix : Dbspica
 - Clix : input/output disks, mail, DNS
 - Mix6 : repository ldac
 - Note : Crontab scripts checks node state regularly
- When hardware failure happens :
 - Find which QF,Stack was running
 - Check Dbspica
 - Check files located on nodes and output disks
 - Unlock and repair or delete
 - Remove stack,QF to clean dbspica

Spica problem interface



File	Runid	Filter	Msg
CFHTLS_Pre-W_r_021955-034400_T0003	Pre-W	r	Failed on /usr/bin/scp mix6/data/mix6/raid1/processing/spica/admin/admin-spica/CFHTLS Pre-W_r_021955-034400_T0003 tmp/CFHTLS_Pre-W_r_021955-034400_T0003
			mix6 is back to life
			mix4 is back to life
			pix3 is back to life
			pix9 is back to life
			pix1 is back to life
			pix2 is back to life
			pix4 is back to life
			pix5 is back to life
			pix8 is back to life
			pix6 is back to life
			pix7 is back to life
			mix3 is back to life
			Unable to contact pix9 via ssh
			Unable to contact pix1 via ssh
			Unable to contact pix6 via ssh
			Unable to contact pix3 via ssh
			Unable to contact pix4 via ssh
			Unable to contact pix5 via ssh
			Unable to contact pix6 via ssh
			Unable to contact pix7 via ssh
			Unable to contact pix2 via ssh
			Unable to contact mix3 via ssh
			Unable to contact mix4 via ssh
805282p_V0003	V0003		Failed on /usr/local/spica/spica_copy.pl -m mix4 -n mix3 -i /data/mix3/raid2/processing/04BL06A.MP9701/764615p/quality/data/mix4/raid2/processing/spica/admin/admin-spica/805282p_V0003/scamp/764615p.Idac - Code 2 - Line 7
805288p_V0003	V0003		Failed on /usr/local/spica/spica_copy.pl -m mix4 -n mix3 -i /data/mix3/raid2/processing/04BL06A.MP9701/764619p/quality/data/mix4/raid2/processing/spica/admin/admin-spica/805288p_V0003/scamp/764619p.Idac - Code 2 - Line 7
805287p_V0003	V0003		Failed on /usr/local/spica/spica_copy.pl -m mix4 -n mix3 -i /data/mix3/raid2/processing/04BL06A.MP9401/757822p/quality/data/mix4/raid2/processing/spica/admin/admin-spica/805287p_V0003/scamp/757822p.Idac - Code 2 - Line 9
805295p_V0003	V0003		Failed on /usr/local/spica/spica_copy.pl -m mix4 -n mix3 -i /data/mix3/raid2/processing/04BL06A.MP9701/764657p/quality/data/mix4/raid2/processing/spica/admin/admin-spica/805295p_V0003/scamp/764657p.Idac - Code 2 - Line 7
805298p_V0003	V0003		Failed on /usr/local/spica/spica_copy.pl -m mix4 -n mix3 -i /data/mix3/raid2/processing/04BL06A.MP9701/764615p/quality/data/mix4/raid2/processing/spica/admin/admin-spica/805298p_V0003/scamp/764615p.Idac - Code 2 - Line 7
805294p_V0003	V0003		Failed on /usr/local/spica/spica_copy.pl -m mix4 -n mix3 -i /data/mix3/raid2/processing/04BL06A.MP9701/764657p/quality/data/mix4/raid2/processing/spica/admin/admin-spica/805294p_V0003/scamp/764657p.Idac - Code 2 - Line 7
805302p_V0003	V0003		Failed on /usr/local/spica/spica_copy.pl -m mix4 -n mix3 -i /data/mix3/raid2/processing/04BL06A.MP9401/757941p/quality/data/mix4/raid2/processing/spica/admin/admin-spica/805302p_V0003/scamp/757941p.Idac - Code 2 - Line 9
805303p_V0003	V0003		Failed on /usr/local/spica/spica_copy.pl -m mix4 -n mix3 -i /data/mix3/raid2/processing/04BL06A.MP9401/757822p/quality/data/mix4/raid2/processing/spica/admin/admin-spica/805303p_V0003/scamp/757822p.Idac - Code 2 - Line 9

- Summary of failures
 - Software
 - Hardware (red)
- Display :
 - File
 - Runid, Filter
 - Error message
 - Date
 - Node
 - Release mode, version

Spica updating

- How to update one (or more) application(s) :
 - Check permission to update (major/minor version number)
 - Install the application(s) on all nodes
 - Change configuration file if needed
 - Update application table in dbspica
- Updating Spica scripts
- Updating dbspica
- Adding a new node
 - Before Stacking
 - Update ClusterNode table in dbspica

F.A.Q. (1)

- I want to test my new software
 - Use Pix3/Pix4 ! ;)
- How to rebuild a stack ?
 - Remove it with the admin interface
 - Rerun spica_auto.pl to regenerate the command file
 - Make sure spica daemon is running
- How to launch Spica ?
 - QFin : spica_ini.pl
 - Stack : spica_auto.pl

F.A.Q. (2)

- What can I do ?
 - Run QFin when spica is running
- What cannot I do ?
 - Remove QFin / Change rank when Spica is running
 - Update application with major version number
 - Change spica command files without deleting them beforehand
 - Selection of files
 - Ahead values
 - ...

Web Interface

- Database Query
 - QFin
 - Stack
 - Individual image (QFin + VeryWide)
- Data Management
 - Ranking QF and stack
 - Removing QFin / Stacks
- Data-mining
 - CPU stats
 - Stack comparison
 - Scamp / Completeness plots

QFin interface

The screenshot displays the QFin web interface. At the top, a summary for 'Runid 04BF28' shows 201 images from data transfer, 3 images with problems, and 196 QF images. Below this are several data tables:

- Filter:** Lists filters like LMP9701 and z.MP9801 with their respective counts.
- Node:** Lists nodes like plat and their counts.
- Grade:** Shows grade distribution (Not graded, A, B, D) with counts.
- Object:** Lists objects like Tau03B-1 and their counts.
- Gruid:** Lists groups like 04B004 and 04B005 with counts.
- ExpTime:** Shows exposure time distribution.
- DataObs:** Lists observation dates and counts.


A 'PI data access' section includes a login form with fields for 'Login' (admin) and 'Password' (****), and a 'Go' button. A warning message states: 'Warning : cannot connect to mix5'.

The main content area displays a 'Qualityfits Processed data' table with columns for Runid, Name, Number, and %. It shows data for Runids 2003, 2004, and 2005, along with a 'Filter' table and a 'Grade' table.


Below the main table is a 'QF in progress... (1)' table with columns for Image, Runid, Filter, Object, and Node, showing a single entry for image 775333p.

At the bottom, a 'Search' panel allows users to filter data by various criteria including Display, QF Version, Filename, Object / Field, Runid, Filter, DateObs, Min & Max, Node, Grade, RA Min & Max, Dec Min & Max, Master flat, Master mask, Exposure time, Airmass, Seeing, Bkg, Skyprobe Min & Max, QF Comment, Phot. c, Status QF, and Min/Max values.

- QFin in progress
- QFin summary
- PI access restricted
- Search utility
 - Processing node, Status
 - Input files (master...)
 - Criteria (runid, filter...)
 - Output fields (seeing...)
- Reprocessing
- Validation
 - Ranking
 - Comments
- Output files :
 - Location
 - Input file, weight, catalog




Stacks removal




- Remove entries :
 - Dbspica
 - Output files
 - Input files
- Spica step :
 - QFin
 - Stacks mode
 - Image mode (VW)
- Group :
 - Filename
 - Runid
 - Node

Data-mining



Completeness



Scamp

Release comparison

TERAPIX Stacks comparison

Home > Tools > Data reduction > Spica

This front panel can be used to select stacks

Search	Display	Node	Mode	Release version	Survey	Filter
Go	5	---	Stack	0003 0002	W	u.MP9301

Stack	Key	0003	0002
CFHTLS_W_u_021410-041200	Scamp number of files	491	106
	Swarp number of files	5	4
	Exposure	2400 s	2400 s
	Median seeing	0.88"	0.89"
	Completeness (80%)	25.162	25.182
	Scamp Internal RMS	0.047" / 0.042" (27 %)	0.037" / 0.031"
	Scamp External RMS	0.343" / 0.341" (8 %)	0.317" / 0.31"
	Median background	3.03	7.94
CFHTLS_W_u_021410-050800	Scamp number of files	493	110
	Swarp number of files	5	5
	Exposure	3000 s	3000 s
	Median seeing	1.09"	1.08"
	Completeness (80%)	24.904	24.975
	Scamp Internal RMS	0.047" / 0.042" (10 %)	0.036" / 0.029"
	Scamp External RMS	0.342" / 0.342" (11 %)	0.307" / 0.301"
	Median background	2.56	5.38
CFHTLS_W_u_021800-041200	Scamp number of files	538	126
	Swarp number of files	5	5
	Exposure	3000 s	3000 s
	Median seeing	0.97"	0.97"
	Completeness (80%)	25.303	25.316
	Scamp Internal RMS	0.045" / 0.04" (10 %)	0.05" / 0.04"
	Scamp External RMS	0.353" / 0.35" (24 %)	0.263" / 0.266"
	Median background	2.38	4.54
CFHTLS_W_u_021800-050800	Scamp number of files	541	126
	Swarp number of files	2	2
	Exposure	1200 s	1200 s
	Median seeing	1"	1"
	Completeness (80%)	24.884	24.946

http://clix.iap.fr/spica/admin/admin-spica/survey/list_app_files.php?filename=CFHTLS_W_u_021410-041200&imgid=173456&appid=56&database_use=dbspica

* Compare several releases :

- Scamp / Swarp files
- Exposure
- Seeing
- Completeness
- Background

...

* Find stack to compare :

- Survey
- Filter
- Release number

...

Pipeline SPICA / Web



« web » interface

- used remotely
- User accounts
- Selection criteria included for user selection of images and configuration files

Elixir - Forms- Step 2 - Mozilla

Configuration - Step 2

swarp

(*) indicates parameters which can be omitted from this config file

Output	Weight type Map weight Help
Astrometry	Celestial type: Native Help Projection type: Distorted tangentiel Help Center type: All Help Coordinates of the image center: 00 00 00.0, +00 00 00.0 Help Pixel scale type: Median Help Pixel scale: 0.0 Help Image size: 0 Help
Resampling	Method: Lanczos3 Help Oversampling in each dimension: 0 Help Interpolate bad input pixels?: Yes Help Flux-scaling factor: Fixed Help
Background subtraction	Subtraction sky background?: Yes Help Background mesh size in pixels: 128 Help Background map filter range in meshes: 0 Help
Co-addition	Combine resampled images?: Yes Help Combine type: Weighted Help
Miscellaneous	Write information about each input file in the output image header?: No Help List of FITS keywords to propagate from the input to the output headers: FILTER,EXPTIME,PHOT_C,PHOT_KA,IRMAAT Help Number of CPU: 2 Help

Submit Reset

Elixir - Login - Mozilla

http://gtlx.iap.fr:8080/spica/login.php?userid=1

TERAPIX Welcome to SPICA

Home > Tools > Data reduction > Spica

Mode cheat

Hello laurent domisse (terapix member)

In order to reduce data, you need first to create generic configuration and rule files.

Define a new process name

Name: Go

List of your defined processes:

Process Id	Process name	Pipeline	Launch	Delete	View Config	Status	Final data control	Archive
<input type="checkbox"/> 8	alpha	Reduction	Go	Go	scamp swarp	Go	Go	Go
<input type="checkbox"/> 7	bert	Reduction	Go	Go	scamp swarp	Go	Go	Go
<input type="checkbox"/> 7	bert	Catalog extraction	Go		ssextractor	Go	Go	
<input type="checkbox"/> 6	bertrand	Reduction	Go	Go	scamp swarp	Go	Go	Go
<input type="checkbox"/> 6	bertrand	Catalog extraction	Go		ssextractor	Go	Go	
<input type="checkbox"/> 4	aa	Reduction	Go	Go	scamp swarp	Go	Go	Go
<input type="checkbox"/> 2	test1	Reduction	Go	Go	scamp swarp	Go	Go	Go
<input type="checkbox"/> 2	test1	Catalog extraction	Go		ssextractor	Go	Go	

selected: launch delete archive

Account management

- Password change
- Group change
- Ganglia
- Sdm

Config management

- Process configuration

History

- View waiting/running
- runid

Archive


- View archive



Forms configuration

- Manage processing configuration


Pipeline SPICA / Web



Results

- Coadded image
- Weighted image
- Flag map
- Metadata
- Catalogue

Web mode



Todo list (1)

- Spica
 - Stacks
 - Ability to move a stack from one node to another one
 - Use previous scamp results for similar stack fields
 - Use external ldac as a reference for the stacks
 - QFin
 - Get masters from CFHT or from others nodes
 - Reprocessing
 - Managing CFHT metadata
 - QF Webservice
 - Autocorrelation
 - WirCam processing
 - More error control (errno, md5sum)
 - Automatic ranking

Todo list (2)


- Packaging
 - Spica Configuration files (SQL + configure)
 - SQL script to install and to fill the database
 - Subversion (spica_core, spica_config, spica_web)
 - Spica standalone
- Spica Web
 - Based on Elixir, Astrometrix, dbterapix, selectix !
 - As a webservice ?

Todo list (3)

- Web Interface
 - Fields sorting and selection, CSS output
 - Remove / Rerun spica
 - Shares configuration files with spica auto (PHP/Perl)
- Database
 - Multi-base, Multi-release, Structure optimisation
 - Uses transactions to secure
 - Store release filter rules
 - Catalog loading and data-mining
- Post-Spica
 - Catalog database
 - Chi2 / Dust / Mask / Color-Color plots

Conclusion

- Not perfect ...
 - Intended to be a 2 month's work
 - Set of patches made as fast as possible
 - Tailored to Megacam
- ... but it works as required !
- Interesting stuff
 - Packaging
 - Adding Wircam
 - Data-mining (catalog)
 - Spica Web



GRRRRRRR...

